

Door reversal on CEV425 and CEV425CP with LED in door frame

1. Unplug the cabinet
2. Dismount the bottom panel to get access to machine room and bottom hinge
3. In the machine room, disconnect the electrical connections to the door frame LED
4. Dismount the canopy to get access to the upper hinge. Dismount the upper hinge, and the door can be taken off at the bottom hinge. The cables for the LED go through the bottom panel and these must carefully be taken along with the door
5. Place the door on a suitable surface to get a good working height



6. The hinge bracket is screwed off and removed



7. Remove the plastic cover in the side of the door and pull the cables out of this hole.



8. Remove the plastic cover in the other side.



9. Put together the cables with adhesive tape to make it easier to put these through the door.



10. Pull the cables all the way through to the other side



11. Take the cables through the hole and mount the plastic cover again



12. Take the cables through the hinge bracket.



13. Remount the hinge bracket.



14. Mount the bottom ?? on the opposite side and mount the door on it.

15. Mount the canopy

16. Remount and connect the door LED cables. Also mount the bottom hinge bracket.

17. Remount the bottom panel

18. The cabinet is ready to be plugged in again