



WARING
COMMERCIAL


Europe *Lund* 7-Quart Stand Mixer
WSM7LE




038360
Unit Assembly




038338
Finger Guard
038339
Screw (2 required)




037794
Splash Guard




038328
Mixer Head Assembly




037795
Bowl




037796
Mixing Paddle



037797
Chef's Whisk




037798
Dough Hook



Date Code Location
WWYY
week week/year year

WARING COMMERCIAL®

Unit Components WSM7LE



Illustration#	Part#	Description
1	037799	Top Cover
2	038331	Light
3	038332	Power Switch
4	038335	Speed Control
5	037803	Speed Control Knob
6	037805	Plastic Cover
7	037804	Screw (2 required)
8	037807	Lead Clamp
9	037804	Screw (1 each clamp)
10	038361	Motor
11	037812	Hex Bolt with Washers (4 required)
12	038340	EMI Filter
13	037813	Screw (2 required)
14	038329	Junction Box
15	038341	Metal Plate
16	037834	Screw with Washers (2 required)
17	037833	Screw (4 required)
18	037832	Nylon Screw (4 required)
19	037841	Push Spacer Stand Offs (4 required)
20	038333	PCB Board
21	037840	Small Rubber Mat (2 required)
22	038336	Square Rubber Mat
23	037813	Screw (3 required)
23	037814	Mixer Head Bottom
25	037818	Screw
26	037819	Spring Washer
27	038347	Hex Head Bolt
28	038348	Washer
29	037842	Screw (2 required)
30	037815	Screen
31	037816	Screw (2 required)
32	037817	Screw (2 required)
32	037823	Shaft Cover (2 required)
34	037824	Shaft

Illustration#	Part#	Description
35	037822	Plum Wrench
36	037821	Stand
37	037820	Bowl Pad
38	038334	Reset Switch
39	037809	Screw with Washers (2 required)
40	038337	Relay Switch
41	038343	Insulation Paper
42	038330	Green/ Yellow Lead Assembly
43	038345	White Rubber Sleeve with Leads
44	038344	Black Rubber Sleeve with Leads
45	037826	Ground Screw
46	037444	Spring Washer
47	038342	Cord
48	038346	Cloth Sleeve
49	037843	Bottom Plate with Feet
50	037844	Screw (5 required)