




Machine	Explode	Code	Description
Buffalo Bakery Convection Oven - 600x400mm Three Phase	1	AW172	Door Seal
Buffalo Bakery Convection Oven - 600x400mm Three Phase	2	AW173	Door Assembly
Buffalo Bakery Convection Oven - 600x400mm Three Phase	3	AW174	Timer
Buffalo Bakery Convection Oven - 600x400mm Three Phase	4	AW175	Timer Knob
Buffalo Bakery Convection Oven - 600x400mm Three Phase	5	AW176	Power/Red Indication Light
Buffalo Bakery Convection Oven - 600x400mm Three Phase	6	AW177	Working/Green Indication Light
Buffalo Bakery Convection Oven - 600x400mm Three Phase	7	AW178	Temperature Knob
Buffalo Bakery Convection Oven - 600x400mm Three Phase	8	AW179	Thermostat
Buffalo Bakery Convection Oven - 600x400mm Three Phase	9	AW180	Manual Humidity Button
Buffalo Bakery Convection Oven - 600x400mm Three Phase	10	AW181	Feet (set 4)
Buffalo Bakery Convection Oven - 600x400mm Three Phase	11	AW182	Door Switch
Buffalo Bakery Convection Oven - 600x400mm Three Phase	12	AW183	Internal Light
Buffalo Bakery Convection Oven - 600x400mm Three Phase	13	AW184	Wire Buckle
Buffalo Bakery Convection Oven - 600x400mm Three Phase	14	AW185	Temperature Limiter
Buffalo Bakery Convection Oven - 600x400mm Three Phase	15	AW186	AC Conductor
Buffalo Bakery Convection Oven - 600x400mm Three Phase	16		UK Power Cord
Buffalo Bakery Convection Oven - 600x400mm Three Phase	17	AW188	Heating Element
Buffalo Bakery Convection Oven - 600x400mm Three Phase	18	AW189	Fan Motor
Buffalo Bakery Convection Oven - 600x400mm Three Phase	19	AW190	Water Pump
Buffalo Bakery Convection Oven - 600x400mm Three Phase	20	AW191	Rebound Device
Buffalo Bakery Convection Oven - 600x400mm Three Phase	21	AW192	Water Tank
Buffalo Bakery Convection Oven - 600x400mm Three Phase	22	AW193	Shelf
Buffalo Bakery Convection Oven - 600x400mm Three Phase	23		Terminal