



# WASTE BIN COOLERS

## Users manual



**Models:**  
WBC240  
WBC480



# CONTENTS

---

1.	General information	
	Important safety instructions .....	4
	Unpacking .....	4
	Electrical connection .....	4
	Thermostat .....	5
	Cleaning and maintenance .....	6
	Service.....	6
	Disposal .....	6

# IMPORTANT SAFETY INSTRUCTIONS

1. To obtain full use of this waste-bin cooler, we recommend reading this instruction manual.
2. It is the user's responsibility to operate the appliance in accordance with the instructions given.
3. Contact your dealer immediately in case of any malfunctions.
4. Place the waste-bin cooler in a dry and ventilated place.
5. Keep the waste-bin cooler away from strongly heat-emitting sources.
6. Always keep in mind that all electrical devices are sources of potential danger.
7. Do not store inflammable material such as thinner, gasoline etc. in the coldroom.
8. We declare that no asbestos nor any CFC are used in the construction.
9. The oil in the compressor does not contain PCB.



## ONLY FOR APPLIANCES WITH REFRIGERANT R290/R600a!

This appliance contains a flammable refrigerant, so make sure of good ventilation around the appliance. Do not use mechanical devices when defrosting, this can cause leakage of the cooling system. Do not use electrical appliances inside the refrigerated storage compartment.

Any repair of the appliance should be carried out by a skilled technician (EN 60335-2-89: 2010).

## UNPACKING

Remove the wooden pallet and the packing. External surfaces are supplied with a protection foil, which must be removed before installation.

If any damages, report to the transporter.

## ELECTRICAL CONNECTION

The waste-bin cooler operates on 220-240 V/50 Hz.

The wall socket should be easily accessible.

All earthing requirements stipulated by the local electricity authorities must be observed. The coldroom plug and wall socket should then give correct earthing. If in doubt, contact your local supplier or authorized electrician.

The main electrical connections must be done by skilled electricians.

# THERMOSTAT



The thermostat has been pre-set and in most cases it is not necessary to adjust the settings. When turning on the cabinet the display will show the current temperature in the cabinet.

## Display set temperature:

**SET** Press this key and the display will show the set temperature. Press the key again to return to normal reading

## Set new temperature:

**SET** Press this key continuously for more than 3 seconds and the display shows the set temperature.



Press this key to increase the set temperature.



Press this key to lower the set temperature.

**SET**

Press this key to save the new settings. The display will flash with the new value and will then return to normal reading.

## Keyboard lock/unlock:

Press these keys simultaneously for 3 seconds. To lock the display reads 'oF'. To unlock the display reads 'on'.

## Alarm codes:

'P1' Flashing in the display: indicates that the cabinet sensor is defective.  
The cabinet will strive to keep the set temperature until it has been repaired.

# DEFROSTING

The cabinet defrosts automatically with pre-set intervals. If the door to the cabinet is opened or the contents of the cabinet is changed frequently it may become necessary to defrost the cabinet manually.



Pressing this key continuously for more than 3 seconds will start a manual defrosting and then return to normal operation.

Defrosted water runs to a container placed in the compressor compartment and evaporates.

# CLEANING AND MAINTENANCE

Switch off the waste-bin cooler at the socket.

The waste-bin cooler must be periodically cleaned. Clean the external and internal surfaces of the cabinet with a light soap solution and subsequently wipe dry. External surfaces can be maintained using steel oil.

Do NOT use cleansers containing chlorine or other harsh cleansers, as these can damage the stainless steel surfaces and the internal cooling system.

Clean the condenser and the compressor compartment using a vacuum cleaner and a stiff brush.

Do NOT hose the compressor compartment with water as this can cause short circuits and damage on the electrical parts.

## SERVICE

The cooling system is a hermetically sealed system and does not require supervision, only cleaning.

If the coldroom fails to cool, check if the reason is a power cut.

If you cannot locate the reason to the failure of the waste-bin cooler, please contact your supplier. Please inform model and serial number of the waste-bin cooler. You can find this information on the rating label which is placed at the side of the waste-bin cooler.

## DISPOSAL

Disposal of the waste-bin cooler must take place in an environmentally correct way. Please note existing regulation on disposal. There may be special requirements and conditions which must be observed.

